



eNEXHO-CL

Thermostat module

Assembly and operating instructions

- › Please read these instructions carefully and keep them for future consultation. eNEXHO range equipment must be installed by an accredited, qualified electrician and must observe Low Voltage Regulations. The installation as a whole should meet the provisions of aforesaid regulation. Any claim presented will be deemed invalid if the prevailing regulations have not been met.

GENERAL INFORMATION

With your choice of ETHERMA you have decided on an ingenious heating solution. We thank you for your confidence. In us you have a competent partner with more than 30 years of experience. ETHERMA relies on constant innovation, highest product quality and modern design.

The following instructions will help you, to use your ETHERMA quality product as effective as possible. They contain important information about safety, installation, use and maintenance of the devices. Please read the information in this instruction carefully and keep them for feedback at a later time on.

We support you with comprehensive personalized services and find the right product solution for you.


SPECIFICATIONS

Emission band:	f = 868 MHz
Consumption:	<1.5 W
Temperature measuring range:	5-35°C (41-95F)
Accuracy:	±1°C
Maximum output current:	5A
Dimensions (Height x Width x Depth):	94 mm x 87 mm x 44 mm
Power supply:	100-240 VAC, 50/60 Hz

INSTALLATION



Please note that the installation button of the eNEXHO-CL thermostat module is located at the rear part of the device, next to the screw terminals. Not absolutely necessary, we advise you to configure the eNEXHO-CL thermostat module in the eNEXHO system before fixing it to the wall mounting plate. This way you will not have to disassemble in order to configure the device.



1. Use the screws provided with the device to fasten the metal wall mounting plate in the appropriate position.
2. Attach the necessary power wires as indicated in the wiring diagram found in this manual.
3. Attach the thermostat module into the wall mounting plate.
4. The device is ready to use.

THERMOSTAT FUNCTIONS, INFORMATION AND SWITCHES



HOW DO I INSERT A TEMPERATURE CORRECTION?

Turn off the display by pressing the ON/OFF button. Immediately afterwards, press the buttons "⌚" and "⊖" for five seconds. The display will show the code "1". Then press "▲" or "▼" buttons to select the correction. Once you have finished, wait until the display goes off or press the ON/OFF button.



Please do not modify any values other than the value with the code "1". Otherwise your thermostat module may stop working properly.

HOW DO I RESET THE eNEXHO-CL THERMOSTAT MODULE?

Press the installation button until you hear the activation of the module relay. Release the installation button and wait until the "⚡" symbol disappears from the thermostat module display. When this happens, the module will have been reset successfully.


HOW DO I ASSOCIATE A eNEXHO-CL THERMOSTAT MODULE TO A POWER- eNEXHO-CR CONTROL MODULE?

The eNEXHO-CL thermostat module enables associations. By associating the eNEXHO-CL thermostat module to one or multiple eNEXHO-CR power-control modules, you can use the power-control modules to control the heating system. This feature can be of interest if there are difficulties with the wiring or if you need a higher output of electricity in your thermostat.

the installation button at the rear part of the eNEXHO-CL thermostat module. Follow the instructions on your system's control equipment to configure a power-control module as ON or OFF. At this point, the association will be ready: the power-control module will turn on the heating system in your home under the supervision of the eNEXHO-CL thermostat module, that is to say, it will maintain the temperature that was previously set in the thermostat by means of the wireless technology.


In order to do this, you must first configure the eNEXHO-CR power-control module in your eNEXHO system and then access the "Settings" menu. Choose the option "Associate module". While the control equipment is awaiting the information, press

CONNECTIONS



WHEN TROUBLESHOOTING
PLEASE CONTACT THE CUSTOMER CARE OF YOUR SPECIALIST DEALER.

INDICATION: Subject to technical modifications. Changes, errors and misprints shall not be entitled to compensation.



WARNING: Electrical and electronic appliances often contain precious materials. But they can also contain harmful substances that were necessary for their function and safety. They can harm the environment if disposed or mishandled. Please help to protect our environment! Therefore do not dispose of this device in the residual waste. Dispose of this unit in accordance with local regulations. Dispose of the packaging materials, replacement parts or equipment parts properly.

GENERAL WARRANTY CONDITIONS

Dear Customer,
 please refer to our terms and conditions common paradigm. In warranty cases inform your dealer directly and he will help you due to country-specific legal claims.

eNEXHO-CL

Distributed by:

Purchase date:

FITTER:

Name:

Adresse:

Telephone:

USER:

Name:

Adresse:

In service:

No:

